

Rear Coil Springs : DuraTPE® Plus Series Size D/ Block Booster Series RB125-1-1

Ground Lifting Height : ~1.2"

If you order wrong size buffers to install on your vehicle. Please contact us immediately. We will arrange replacement buffers for you.

(Do not Copy) These instructions are part of an Installation manual that is under Copyright Protection by RubberShox®/DuraSHOCK®

Note: This product gives added support for automotive coil springs to prevent sagging. It also provides a stiffer/more stable suspension that absorbs and dissipates the shock from potholes and rough roads. This product reduces stress on tires and the suspension which will enhance the vehicle's operational life span.



1. Jack up the SUV and put safety lift stop.



2. The measurement of the spring gap was 1.1" so CSBPlus-D size D and RB125-1-1 were selected.



3. The backend is raised 1.2". The springs are old and saggy, so we get more ground clearance.