

Replaced the factory bump stops with Universal Rubber Bump Stops UB1+UB2 w/ Z1-UBS bracket

(Do not Copy) These instructions are part of an Installation manual that is under Copyright Protection by RubberShox®/DuraSHOCK®
If you order wrong size buffers to install on your vehicle. Please contact us immediately. We will arrange replacement buffers for you.

