

IMPORTANT NOTICE: RUBBERSHOX INSTALLERS SHOULD APPLY COMMON AUTOMOTIVE SAFETY PRACTICES WHEN RAISING, LOWERING AND WORKING ON VEHICLES, ALWAYS WEARING SAFETY GLASSES, USING BOTH HYDRAULIC JACK AND JACK STAND DURING THE INSTALLATION. We recommend that this installation be done by a professional or person with auto mechanical knowledge.



Use the template to choose the correct buffer for the front coil spring after lifting up the truck. It shown size E on the template.



This truck coil spring diameter is too big, so it is very hard to install the buffer. We cut of the top inner ring to ease the installation.



Tight up the buffer on top of the coil spring with included zip ties.