

Installation Case Study 2015 Mercedes Benz Springer 2500

Replaced the factory bump stops with Universal Rubber Bump Stop UB1+UB3 (Do not Copy) These instructions are part of an Installation manual that is under Copyright Protection by RubberShox®

















