

## **Installation Case Study** 2013 Ram Promaster 1500

Replaced the factory bump stops with Universal Rubber Bump Stops UB1223 (Do not Copy) These instructions are part of an Installation manual that is under Copyright Protection by RubberShox®









**Before** 



After



If you order wrong size buffers to install on your vehicle. Please contact us immediately. We will arrange replacement buffers for you.